



Make & Model	From	To	BONNET CABLE #
BMW			
3-SERIES			
3-SERIES, ALL E36 MODELS	94	99	BONNET:20-101 /BONNET:20-101L
CHANA			
RAINBOW			
RAINBOW 1.0, 1.3 BUS, P/VAN	06	12	BONNET:29-07
STAR			
STAR 1.0, 1.3 BUS, P/UP, P/VAN, CLUB CAB	06	12	BONNET:29-07
FIAT			
UNO ALL MODELS	94	04	BONNET:30-93
FORD			
BANTAM			
BANTAM ALL MODELS	94	12	BONNET:33-241
COURIER			
COURIER ALL MODELS	94	00	BONNET:33-241
IKON			
IKON 1.3i, 1.6i, L, LX, CLX	01	08	BONNET:33-247
HONDA			
BALLADE			
BALLADE 150, 160, 180	94	00	BONNET:45-170
HYUNDAI			
ATOS			
ATOSPRIME 1.0, 1.1	99	13	BONNET:75-95
ELANTRA			
ELANTRA 1.6 GLS , 1.8GLi (J1)	93	95	BONNET:75-91
i10			
i10 ALL MODELS	12	ON	BONNET:75-99
ISUZU			
KB250			
KB250c, Dc Dsl, LE, D/CAB, P/UP, LWB, FLEETSIDE	08	13	BONNET:22-204 / BONNET:22-201
KB250 DTEQ LE, D/Cab, X-CAB	07	ON	BONNET:22-686



Make & Model	From	To	BONNET CABLE #
KIA			
PICANTO			
PICANTO	05	09	BONNET:48-81
mitsubishi			
COLT			
COLT ALL MODELS	94	06	BONNET:57-212
NISSAN			
ALMERA			
ALMERA	01	06	BONNET:26-698
TIIDA			
TIIDA ALL MODELS	06	14	BONNET:26-305
1400			
1400 ALL MODELS	94	10	BONNET:26-305
HARDBODY			
HARDBODY	96	03	BONNET:26-698
NP 300			
NP 300	08	14	BONNET:26-697 (WITH LEVER) / BONNET:26-700 (W/OUT LEVER)
OPEL			
ASTRA			
ASTRA ALL MODELS	94	06	BONNET:61-220 / BONNET:61-221
CORSA			
CORSA I (B) ALL MODELS	96	02	BONNET:61-333
CORSA II (C) ALL MODELS including Gamma	03	08	BONNET:61-345
CORSA UTILITY			
CORSA UTILITY I, II, III ALL MODELS	97	10	BONNET:61-333
TATA			
INDICA			
INDICA 1.4 LEi, LSi, LX, LXi	04	ON	BONNET:77-13
INDIGO			
INDIGO 1.4 GLS, GLX, S/WAGON	12/04	ON	BONNET:77-13
TOYOTA			
AVANZA			
AVANZA ALL MODELS	08	ON	BONNET:82-697



Make & Model	From	To	BONNET CABLE #
CONQUEST			
CONQUEST ALL MODELS	94	10	BONNET: 82-677 BOOT:82-695
COROLLA			
COROLLA ALL MODELS	86	96	BOOT:82-738
COROLLA ALL MODELS	94	10	BONNET:82-677 / BONNET:82-694 (02-08) BOOT:82-694
COROLLA (Professional)	07	14	BONNET:82-737 BOOT:82-740
CAMRY			
CAMRY I 200i, Si, 220Si, Sei, 300 SEi (35/FE)	94	01	BOOT: 82-731
CAMRY II	01	06	BONNET:82-736
HILUX			
HILUX ALL MODELS	94	04	BONNET:82-683 / BONNET:82-683L
HILUX ALL MODELS	05	ON	BONNET:82-741
QUANTUM			
QUANTUM TAXI ALL MODELS	05	ON	BONNET:82-739
TAZZ			
TAZZ , CONQUEST ALL MODELS	01	10	BONNET:82-677 BOOT: 82-695
YARIS			
YARIS ALL MODELS	05	13	BONNET:82-724 BOOT: 82-696
VOLKSWAGEN			
CADDY VAN			
CADDY I ALL MODELS	96	07	BONNET:92-363
CITI GOLF			
CITI GOLF ALL MODELS	94	10	1000mm: BONNET:92-356, 732mm: BONNET:92-357, 1800mm: BONNET:92-358, 2000mm with T handle: B2000
FOX			
FOX ALL MODELS	94	95	B2000



Make & Model	From	To	BONNET CABLE #
GOLF IV			
GOLF IV ALL MODELS	99	04	BONNET:92-359
POLO			
POLO I CLASSIC	96	03	BONNET: 92-374
POLO II, IV (VIVO) ALL MODELS	02	10	BONNET:92-360
UNIVERSAL BONNET CABLES			
2000mm with BONNET lever			B 2000
2000mm with screw-on small T handle			T2000
3000mm with screw-on small T handle			T3000 / T3000B(bowden)
4000mm with screw-on small T handle			T4000
3000mm with screw-on small T handle, Bowden inner			T3000 B